

Reset

Disconnect electricity and take the batteries out of remote control and put everything back. You have then 5 minutes to reset.



1. look first if you have this screen like fig 1.
2. Push on menu button for +/- 5 sec till you see 24:00 in left corner above.
3. Push again till you see nr1 in left corner above
4. Push again till you see the clock symbol in left corner
5. Push again till you see "bnd".
Push once on the two arrows to communicate with fireplace. Then your fireplace is reset and come automatically in manual mode.